

# **Type 2**



**1977 Volkswagen Owner's Manual**

**Before Driving**

**Operating Controls**

**Climate Controls**

**Do-it-yourself Service**

**Emission Control**

**Technical Data**

**Gas Station Information**



# Contents


Accelerator pedal	28	Defogging and defrosting	34	Headlights	43
Air cleaner	59	Dimensions	79	Headlight dimmer	22
Alternator warning light	19	Do-it-yourself service	38-65	Headlight switch	21
Ashtrays	23	Doors	9, 60	Heater / Defroster	33
Assist handles and coat hooks	24	EGR light	19	Head restraints	11
Automatic Transmission	28	Electrical system	78	High altitude operation	74
Automatic Transmission fluid	58	Emergency flasher	21	Horn	12
Auxiliary heater	36, 37	Emergency starting	30, 64	Ignition / steering lock	17
Back-up lights	44	Emission Control System	70-73	Instrument illumination	21
Battery	62-64	Engine compartment	54	Instrument panel	16
Brake fluid reservoir	61	Engine number	8	Interior lights	23, 45
Brakes	28	Engine oil, changing / checking	56, 57	Jack	46
Brake warning light	20, 28	Engine oil grades	81	Key	8
Bulb chart	42	Fuel economy	27	Kickdown	30
Buzzer	17	Fuel gauge	18		
Capacities	77	Fuel supply	26		
Catalytic converter	19, 25, 26, 71	Fuses and relays	40, 41		
Chassis number	8	Gas Station Information	84		
Cleaning your VW	38, 39	Gearshift lever	32		
Clutch pedal	32				



Lane changer .....	22	Rear view mirrors .....	23	Technical data .....	75–79
License plate light .....	44	Rear window defogger .....	21	Tires .....	51–53
Lights .....	21, 43–45	Reverse .....	29, 32	Tool kit .....	46
Lubricants .....	81	Safe driving hints .....	6	Towing and trailer hauling .....	65
Lubrication .....	60	Safety belts .....	14, 15	Transmission oil grades .....	81
Luggage compartment .....	24	Seats .....	11–13	Troubleshooting .....	66–69
Manual Transmission .....	32	Selector lever .....	29	Turn signal/headlight dimmer switch lever .....	22
Manual Transmission oil .....	58, 81	Side marker lights .....	21, 43, 44	Undercoating .....	73
Note to Owners .....	2	Sliding door .....	10	Unleaded fuel .....	26, 75
Oil pressure warning light .....	18	Sliding roof .....	36	Vehicle Identification .....	8
Parking brake .....	29	Spare wheel .....	46, 51	Ventilation .....	34
		Spark plugs .....	55	Warning lights .....	18–20
		Specifications .....	75–79	Weights .....	79
		Speedometer .....	20	Wheel changing .....	46–49
		Speed ranges .....	5, 32	Windows .....	9
		Starting hints .....	25	Windshield washer fluid container ..	61
		Sun roof .....	36	Windshield wiper/washer lever .....	22
		Sun visors .....	23	Winter operation .....	50



**Genuine VW Parts:**  
**The people who built**  
**your VW**  
**used them.**  
**And so should you.**





**There's nothing but  
Genuine VW Parts in  
your new VW.**

**That's one reason why it  
runs like a new VW.**

No one knows your new VW in quite the same way as the people who built it. And when it comes to replacement parts, we build them to the same standards and specifications as original equipment. So you can be sure of proper VW fit and customary VW performance every time.


As your VW gets on in years, you may find that some genuine VW replacement parts are different from the original parts. That's because when we improve a part for new VWs, there are times when we make the same improvement available for older VWs.

And the only way you can be sure of getting these improvements is with Genuine VW Parts.

One more thing you get with Genuine VW Parts—even after your new car warranty has run out—is warranty protection on every replacement part. Under our Limited Parts Warranty we will repair or replace every defective Genuine VW Part for 6 months or 6,000 miles, whichever comes first.\*

And to be sure you're getting Genuine VW Parts, look for this symbol on the package. It stands for VW quality.

Shown on the opposite page are just a few of the genuine VW replacement parts available at our Parts Department. We'll be glad to help you select the right ones for your VW.









**Autobahn Accessories:**  
They can turn your new VW into  
your personalized VW.

Autobahn Accessories help personalize your new VW and turn it into an expression of your own individual taste, style and interests.

And because they're Autobahn Accessories, they match your VW exactly. And fit exactly, too.

For music and news, there's a selection of AM/FM and AM/FM stereo radios. Including one that also plays 8-track tapes. For added dash, add a set of wheel covers or a racy set of stripes. For added visibility, there's a brace of fog lamps. For added protection, add bumper overriders and floor mats. And for the long haul, add a trailer hitch and roof rack.

These are just a few of the many ways you can turn your own VW into your personalized VW. See our Parts Department for assistance in selecting from our complete line of accessories.

# Autobahn®





# GAS STATION INFORMATION

## Starting

Manual Transmission – Start in Neutral.  
Autom. Transmission – Start in Neutral or Park.

It is not necessary to depress accelerator. Fuel injection system supplies required amount of fuel for starting.

## Driving ranges

See shift pattern on ashtray.


## Chassis number (Serial No., VIN)

Visible through driver's side of windshield.

## Driver's seat

To **adjust seat**, push or pull lever (1) on left.

To **adjust backrest**, push lever (2) down on inboard side of seat.



## Fuel cap

Above right rear wheel.

## Fuel recommendation


UNLEADED FUEL ONLY for cars so marked.

REGULAR, 91 RON, for cars not specially marked. See page 25.

## Engine oil dipstick

Check oil level 5 min. after engine has stopped. Level should be between upper and lower marks on dipstick.

The difference between the two marks is about 0.5 U.S. quarts (0.4 Imp. qt./0.5 liter).



B = dipstick  
C = oil filler cap

## Engine oil grades

Use quality oil labeled "For Service API/SE". See oil viscosity chart on page 81.

## Transmission oil

Manual Transmission – hypoid oil\* SAE 80 W or SAE 80 W-90 (multi-grade), MIL-L-2105 API/GL 4.


**Automatic Transmission:** final drive – hypoid oil\* SAE 90, MIL-L-2105 B, API/GL 5.

\* Lifetime filling

## ATF (Automatic Transmission)

Check ATF level when ATF is warm, with engine idling, selector lever in Neutral and parking brake applied. ATF tank cap has dipstick attached.

Use ATF "Dexron®"



D = filler cap  
E = dipstick  
F = fluid tank



## At a glance . . .

STOCK HIGH-PERFORMANCE

# TUNE-A-BUG

★ Specializing in Volkswagens ★  
FULL SERVICE

Mon.-Fri., 9 to 5  
Sat. 9 to 12  
(407) 830-7153

930 N. Hwy. 17-92  
Longwood, FL  
(1 mile north of 434)

### ENGINE

Horsepower SAE net	67 at 4200 rpm
No. of cylinders	4
Displacement	1970 cc (120.2 cu.in.)
Type	horizontally opposed, rear mount
Cooling	air cooling by fan on crankshaft
Fuel / air supply	AFC fuel injection
Fuel tank capacity	14.6 US gal/12 Imp.gal/55 liters
Engine oil capacity:	
with filter change	3.7 US qts/3.1 Imp.qts/3.5 liters
w/o filter change	3.2 US qts/2.6 Imp.qts/3.0 liters

VEHICLE LENGTH	177.4 in./4505 mm
VEHICLE WIDTH	67.7 in./1720 mm
VEHICLE HEIGHT*	
— Station Wagon	77.0 in./1955 mm
— Campmobile	80.0 in./2032 mm

\* unladen

### BRAKES

dual circuit power-assisted  
discs front, drums rear

### SUSPENSION STEERING

4-wheel independent  
roller steering

### DRIVE TRAIN

Type	rear wheel drive
Gears (Manual)	4 forward, 1 reverse
Speeds (Automatic)	3 forward, 1 reverse

### ELECTRICAL SYSTEM

Battery	Us: 12 Volt/54 Amp. Canada: 12 Volt/63 Amp.
Alternator	US: 55 Amp. max. Canada: 70 Amp. max.